





SARNO DINING CHAIR


Gather Your Eggs...



Legs



Seat Back



Seat



10x Button Head Screw




2x Wood Screw



Allen Key

Note: Please retain all boxes until you are certain that your product isn't damaged and that you do not wish to return it. Disposal of boxes may prevent/delay our ability to resolve your request.

Step 1: Assemble the Legs



Leg Side A


Leg Side B

Distinguish Leg A and Leg B from their notches.

Leg B slots into Leg A


(Leg A, notch faces up. Leg B, notch faces down).

Facing the front of the chair, make sure the back of Leg A is on the left and Leg B is on the right.




Leg Notches

Assembled legs will criss-cross each other




NOTE: Make sure the legs are oriented correctly. When crossed together the legs will appear wider if placed incorrectly.



Correct




Incorrect

Step 2: Place the Seat





Place the Seat down on the criss-crossed legs.

Push the seat all the way back into the notches in the rear of the legs.




Hand tighten the button head screws through the holes from the bottom. Do not fully tighten yet.

Step 3: Attach the Back



Use the slotted wood screws and tighten into the seat back until the screw is flush with the surface.

Step 4: Tighten the Seat Screws



Using the provided allen key,
go back and tighten the screws
on the bottom of the frame.



DONE!